LED Floor Lamp

FL46660

START FROM HERE

- Prepare everything in a clear area
- Wear gloves at all times during this installation
- · Read instructions carefully before you start assembly
- Keep this installation sheet for future reference

Please Note

- This Kuzco LED fixture comes with pre-wired LED module(s)
- Unless instructed, Do Not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage
- Touch dimming

3h.

Technical Support: 1-855-855-8926

- 1. Remove fixture from its original package
- **2.** Apply appropriate amount of glue to threaded joint, wait two minutes for glue to activate, and then connect the rods **(2d)** together.
- 3. Insert into base connector (3f) and use wrench provided (3a) to tighten lock nut (3e) in place and thread on cover (3g).
- 4. Gently slide lamp head (3c) onto magnetic conenctor (3d)
- **5.** Plug driver (3h) into outlet.



