### QUOIZEL GOOSE CREEK, SC. 29445 www. quoizel. com

Quoizel, Inc. 6 Corporate Parkway Goose Creek, SC 29445

Customer Service Phone 631 273 2700 Fax 631.231.7102 www.quoizel.com

# Assembly Instruction Sheet #IS-TF6898M For Style TF6898M

Please go to www.quoizel.com for product cleaning tips. Go to the Care + Maintenance selection.

Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.

Light Source: (2) A 19 Medium Base 60 W Maximum. Alternate Bulbs (2) 13 W CFL.

Estimated Assembly Time: 10-15 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.

## 🛆 Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.


Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

## Care of Tiffany Style Shade


A new tiffany lamp shade has an oil film applied to the shade that protects the tiffany shade from scratches during shipment. If the oil applied is too heavy you can remove the excess oil film with a paper towel. Gently wipe away the excess oil.

For general cleaning of tiffany shades use a gentle lemon oil-based furniture polish applied to a soft cloth and wipe gently.

If a white powder appears on the soldered joints of the tiffany shade this is a normal oxidation process. Use a small amount of lemon oil or mineral oil applied directly to oxidized areas and the soldered area will return to like new.




### STEP 1 - Install Stem with Knurled Nuts



#### STEP 2 - Install Spacer Tube and the Shade

- A. Place the Spacer Tube (E) and the Check Ring (D) over the Stem (F). Secure by threading the Small Knurled Nut onto the Stem (F). Hand tighten until snug.
- D. Thread the Big Knurled Nut onto the stem. The Knurled Nut may be adjusted up or down on the stem to allow the Shade (A) to be positioned correctly so that the Finial (C) can be hand tightened onto the shade.
- C. Place the Shade (A) and Flat Washer (F) over the Stem (G) and secure with thé Finial (C). Hand tighten until snug.




С

#### STEP 3 - Install Bulb

- A. This fixture uses standard bulb with medium base. Maximum 60 watts.
- B. Insert bulb and screw snugly into place.

Your fixture is now assembled and ready to use. Enjoy!







Bulb Socket

**Bottom View** 

Thank you for purchasing a Quoizel product. Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700 or visit us on-line at www.quoizel.com

January 2015







(2) 60W Medium Base Bulbs (Not Supplied)

NOTE: ALL DIMENSIONS ARE ROUNDED UP TO THE NEAREST 1/2"

NO	PART NUMBER	REPLACEMENT PART DESCRIPTION	REQ.
1	16898MTF	BASE MULTI TABLE LAMP	1
2	M1282FIM	FINIAL MULTI 1H X 1.5D	1
3	G622SH	GLASS TIFFANY 7.5H X 14W TF6898M	1